

Manual expander VST-22B



Tube diameter	1/4", 5/16", 3/8", 1/2", 5/8", 3/4", 7/8" 6, 8, 10, 12, 16, 18, 22 mm
Application	soft copper tubes
Packaging	blister

Pictures of some products may vary. Every effort has been made to ensure that the information contained in this catalog is correct. Due to constant technological development, we reserve the right to make changes without notice.

Manual expander VST-22B

Manual expander VALUE to expand copper tubes.

